

Acesonic® BDK-2000

Blu-ray Disc Multimedia Karaoke Player

World's First Multimedia Karaoke Player



Recording, Ripping and Reserving Songs

How to use the BDK-2000's New Features:

Ripping Tracks into MP3G

1. Insert a CD+G
2. Press the "Setup" button on the remote control to launch the Ripping menu
3. Use the up/down directional arrows to highlight the desired tracks and press "Enter" to select
4. Select Yellow (C) button on the remote control to begin

Reserving Songs from the Tracklist Screen

- Use the Green (B) button on the remote control to add songs
- Use the Yellow (C) button to open your playlist
- Sort by moving tracks up the playlist using the Green (B) button on the remote control

Record Your Performance to MP3

1. Highlight a CD+G or MP3+G song
2. Press the Blue Record Button (D) on the remote
3. Click on the song name and rename as desired using the on-screen keyboard and select "ENTER" when done..
4. Select "OK" prompt.
5. Choose the desired storage device and select "ENTER"

Recording a speech, dictation or other audio captured by the microphone to MP3

Insert a compatible storage device before starting.

1. From the Home Screen, press the "ANGLE" button on the remote control (A red recording indicator will appear in upper left-hand of screen)
2. Press the "STOP" button to end recording.